



Establish position for the tap on the sink and drill an appropriate sized hole. Install the T-line diverter valve into the cold water line. Install pressure reducing valve upstream of the filters. Install the Filters in the order shown in this diagram

Please read: The individual filter instructions as well as the instructions for the John Guest connectors.

Flush whole system for 5 minutes once installation is complete. Always check for leaks

Working Pressure: 15 – 55 PSI. Please note: the pressure reducing valve needs to be installed for higher water pressures than 55PSI.

Working Temperature: 5 – 40°C

Wall brackets are provided for mounting of the System and cartridge to the cupboard wall.

Waterflow speed: Tune T-line valve so water flow is approx 2 l/min

Please note: Professional installation is recommended.

Ionza is not responsible for any damage resulting from incorrect installation.